

The Judge 2.0

Owner's Manual



Rocky Mountain™
RADAR

Specifications:

Radar & Laser Detector:

Frequencies:	10.525 GHz 24.125 GHz 33-36 GHz 904 Nano-meter
Sensitivity:	X - 110 Dbm K -124 Dbm Ka wide - 124 Dbm Laser < 200 nano-watt
Alarm:	Separate for each Band Variable alarm for Range
Controls:	Menu, Volume, On/Off, Voice, Language, Tone, Dim, Mute, City/Highway, Test, Scrambler, Factory Reset
Spectre: VG-2:	100% Undetectable [Spectre I, II III; VG-2, 3]
Size:	1.4" x 3.7" x 4.6"

INTRODUCTION

Dear Owner,

Congratulations on your purchase of the world's most sophisticated radar and laser detector and scrambler. The Judge 2.0 is a completely integrated radar and laser detector which responds not only to all the radar guns in use today, but to the other latest development in speed monitoring devices-laser guns.

The Judge 2.0 is the result of Rocky Mountain Radar's commitment to provide you, our valued customer, with the most innovative technologically advanced radar and laser detectors on the market. The Judge 2.0 was created for drivers who will not settle for anything less than the best.

Features:

5 Mile Detection Range:

Full 360° Radar and Laser Detection Full, 5 mile detection of all bands and frequencies used by police, including X, K, Ka, super wide bands and all laser. This radar detector uses micro-scan. It enables our detectors to scan 2-4 times faster than any other detector, which gives you a 100% probability of detecting POP Radar. This technology is unique to Rocky Mountain Radar detectors.

Early Warning Discriminator: (EWD)

The EWD filter prevents false alarms emitted by safety sensors in newer vehicles and over the road drivers.

Traffic Sensor Rejection: (TSR)

The TSR prevents false alerts transmitted by sensors that monitor the traffic flow on roadways around major cities.

Super Clear OLED Display:

The screen is clearly visible in all lighting conditions, so you don't lose focus in any way from the road.

Undetectable to Police: (detector detectors)

The Judge 2.0 radar detector and laser detector incorporates a Monolithic Microwave Integrated Circuit (MMIC), which reduces internal signals from leaking out of the antenna by up to 1/1,000,000 (one millionth) of previous levels which makes the unit totally undetectable to police.

Radar/Laser Scrambling:

Police radar/LIDAR guns need to get multiple readings sequentially in order to display a valid speed to the officer. When The Judge 2.0 detects a speed detection device, it floods the signal with additional signals making it impossible for the speed detection device to get an accurate reading.

WARRANTY:

This unit (The Judge 2.0) comes with a 3-year (36 month) warranty. **Must Have Proof of Purchase**

Speeding ticket rebate:

This unit comes with a 1 year of the Speeding Ticket Protection Program. If you get a speeding ticket while using our product, we'll pay your ticket.

This product has been designed and certified to comply with part 15 of the FCC rules. Any changes or modifications not expressly approved by Rocky Mountain Radar may void your authority to use this product.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Controls



Slot for windshield bracket mount



Rear laser eye
360° laser detection

Front laser eye
360° laser detection

Power Jack
12v DC

Speaker

CITY

Activates CITY or HIGHWAY mode
(Hold CITY button to activate/deactivate scrambler)
(changes setting when in menu mode)

MUTE

Switches between mute options
Mute Off-audio on
Mute On-quiet operation,
Automute-4 quick alerts then self mutes
(changes settings when in menu mode)

Installation

Best place to mount the unit:

You will get the best performance from your detector if you mount it approximately in the center of the windshield, as close as possible to the rear view mirror without obstructing the unit's view of the road either to the front or rear. Make sure unit is level with the road. Dash mount is not recommended. The unit's Laser lens must not be blocked and the Laser Lens should have a clear view out of the back window to allow 360° Laser detection.

Radar and laser signals pass through glass but not through other materials and objects such as:

- Windshield wipers
- Sun shades
- Metallic tinting on the windshield
- Heated windshields

(Instaclear for Ford, Electriclear for GM.)

Mounting the Unit:

1.) Place the suction cups on the windshield bracket.

2.) Place the windshield bracket into The Judge 2.0.

Align the edge of the bracket with the slot opening on the front of the case. Gently slide the bracket into the case **while pressing the bracket release button** until it locks into place. To release bracket, press the bracket release button as you slide out the bracket.

To prevent damage to the unit you must press the release button to release windshield mount before pulling it out.



3.) Clean the windshield before you mount the unit for better results. Place the windshield bracket in the upper center portion of the windshield. The ideal position will be right below the rear view mirror. Make sure the unit has an unobstructed view of the road. Then Press firmly to seat suction cups.

4.) Carefully bend the windshield bracket mount to a level position.

5.) Insert the small end of the power cord gently into the power jack on the right side of the unit and the large end into the cigarette lighter receptacle.



Remote-mounting is not recommended

Dash Mounting is not recommended

Hardwire: Remove cigarette lighter plug. Connect the red wire to +12 Volts, and connect the white wire to ground.

Settings:

When changing the Settings on your detector, please keep in mind:

- Buttons have multiple functions.
- All current settings will be stored in memory.

Controls: There are 4 buttons on top of The Judge 2.0, Menu, Dim, Mute and City.



Menu: Press and hold the Menu button down for an extended period of time (approximately 3 to 5 seconds) to go into Menu Mode. Display will show “Menu” with one beep. When Menu Mode is displayed, press and release the Menu button in step increments to scroll up or the Dim button to scroll down on menu items, once the desired menu item is reached press the Mute or City button to change the setting.

Note: If no button is pressed for approximately 10 seconds The Judge 2.0 will automatically “Exit” the Menu mode.

The Menu items are:

- 1.) Voice On/Off
- 2.) Language Mode English/ Spanish
- 3.) Alarm Tone High/Low
- 4.) X Band On/Off
- 5.) K Band On/Off
- 6.) Ka Band On/Off
- 7.) Laser On/Off
- 8.) K Wide/Narrow
- 9.) Ka Wide/Narrow

- 10.) K Filter (EWD) On/Off
- 11.) TSRF (TSF) On/Off
- 12.) Voltage Meter On/Off
- 13.) Scrambler On/Off
- 14.) Self-Test On/off
- 15.) Factory Reset
- 16.) Exit

Warning: It is your responsibility to be familiar with all laws applicable to the possession and use of Radar Detectors in your locality. The manufacturer and retailer assume no liability or responsibility for use or application of this product in Violation of any applicable law. Please check your state and local laws and regulations of this product.

Rocky Mountain Radar does not condone the use of excessive speed on the highways, nor does it endorse breaking the speed limit laws of the United States of America. Please drive safely when using this or any other electronic device in your car.

Dim: To adjust brightness press the Dim button for a split second (momentary contact) to select between Bright, Dim, Dimmer, Dark. To brighten the alarm light, press the Dim button again until you reach desired setting. In Dark mode there will be a small dot moving from left to right on the display, letting you know that the unit is still powered on. If using Dark Mode the unit will alert with audio of the presence of radar or laser, but **not visually.**

Note: If the unit is in Dark mode the Mute mode cannot be engaged.

Mute: Press the Mute button for a split second (momentary contact) to select “Mute On”, “Auto Mute”, or “Mute Off”. Mute On mode disables voice and beeping sounds for quiet operation. “Auto Mute” mode will alarm 4 times then go into Mute mode, the display will keep alerting with no sound unless a new signal is received.

City: Engage the city function to reduce false alarms in high RF noise areas. City function reduces the X band sensitivity by 50%. Highway mode has all bands at 100% sensitivity.

Reminder: If you forget the settings you last used on the unit use the “Factory Reset?” found on the Menu. Unit will reset to factory default.

Factory Default Mode Settings: Bright, Mute off, Highway, Voice on, English Voice, High tone, K filter on, Scrambler on, Self-Test on, Voltage meter on, TSRF on, X Band on, K Band on, Ka Band on, Laser on, K Wide, Ka Wide.

Self-Test Mode: Begins right after the start message “Rocky Mountain Radar” detection alarms with signal strength will be displayed along with the user preferred activated settings-scrambler test, voice, language and

alarm tone. Self-test mode can be de-activated through the Menu selection.

Reminder! The Judge 2.0 will memorize the settings of the features above when the unit is powered off. Be sure to re-adjust the settings to your normal preferences!

Caution!

Note: To prevent possible heat damage or theft, do not leave the unit in direct sunlight or plain sight when not in use.

Alarms: A separate alert tone will sound for each band of radar encountered with frequency band displayed X, K, Ka or Laser. For X, K and Ka band the signal strength indicators are displayed with arrows and numerically. Tone frequency will increase as signal strength becomes stronger.

Signal Strength: Signal Strength will be first indicated by the display of arrows followed by a number 1-5. When all 5 arrows and the number 5 are displayed the signal is at the strongest level.

VG-2, VG-3 and Spectre: The Judge 2.0 is 100% Undetectable. **On The Judge 2.0 the new MMIC prevents detection of the radar detector completely.**

Auto Memory: The Judge 2.0 has an automatic memory. Any setting enabled when the unit is turned off

will still be enabled when the unit is turned back on. **If you have set the unit on Mute or have Dimmed the display be sure to readjust the settings to your normal preference.**

The Judge 2.0 gives you the option to de-activate X, K, Ka and Laser. Caution must be used when deactivating the radar bands, if you do not know the type of speed monitoring device used by police in your area.

The Judge 2.0 features K Narrow and K wide mode. K Wide operates at full detection strength. K Narrow is a very useful feature, where the frequency range swept in the K-band region is reduced and more centered around a tuned police radar gun.

The Judge 2.0 features Ka Narrow and Ka wide mode. Ka Wide operates at full detection strength. Ka Narrow focuses the detector on the police radars frequencies used in the USA, 33.8 Ghz, 34.7 Ghz, and 35.5 Ghz .

The Judge 2.0 has a built in Voltage Meter that checks and displays vehicle battery voltage when the mode is activated.

Tamper Fee: Tampering with, disassembly, or modification of this product voids the warranty and a fee of \$150.00 will be charged to repair it.

Radar Scrambler Specifications:

Frequencies:	8.0-38.2 GHz
Antenna:	Dual Ridge cast waveguide
Mixer:	Custom MM wave Schottky
Doppler: Generator	Pseudo Random Digital Noise

Lidar Scrambler:

Full Laser coverage using asynchronous pulse position modulation to confuse the lidar computer.

How does it work?

The Rocky Mountain Radar scramblers are full-featured radar and laser scramblers combining active laser and passive radar scrambling capabilities.

The radar scrambling circuit mixes Pseudo Random Digital Noise Generator (PRDNS) with the incoming police radar signal and reflects it back to the radar gun. The computer in the radar gun must receive eight identical, consecutive readings before it will display your speed. All the different speeds contained in the White

Noise confuse the computer in the radar gun so it does not display any speed. This effect duplicates the normal operation that the officer often observes.

Since it is normal to occasionally lose the target speed, the officer is not suspicious. Reasonable care should be used as flagrant violators could still be caught with an estimated speed.

The laser scrambling circuit transmits a series of pulses at the same wavelength used by the police laser guns (Lidar), which are electronically timed at about 100 feet apart. When the pulses pass through the windshield they will lose up to 50% of their power. The power output is 6 to 10 times that needed to trigger the detector in the laser gun. Lidar sends out laser pulses and measures how long it takes to hit your car and come back. From the speed of light, it can determine your *range*. It sends out several more pulses and calculates your speed from the change in distance over time. The Rocky Mountain Radar scramblers only allow the Lidar to see up to 100 feet so it is unable to calculate your speed.

Scrambler Activation:

All Scramblers are factory set to the off Position:

Scrambler: To turn the scrambler on/off:

Note: If no button is pressed for approximately 10 seconds The Judge 2.0 will automatically “Exit” the Menu mode.

1. Press and hold the Menu button approximately 3-5 seconds or until “MENU” is displayed.
2. Press the Menu button in increments until “Scrambler” is displayed
3. Press the Mute or City button to turn scrambler on/off.

If the scrambler is on, “Scrambler Test” will be displayed in the startup sequence. When the unit’s scrambler setting is set to off, then “Scrambler off” will be displayed in the startup sequence. During the startup sequence the current menu settings are displayed. If “Self-Test mode” setting is de-activated the unit will only show current settings on the display.

To activate or de-activate scrambler quickly press and hold the City button for an extended period of time (3 to 5 seconds)

Limited Warranty

The manufacturer warrants The Judge 2.0 against all defects in materials and workmanship for the period of 36 months from the date of the original purchase, subject to the following terms and conditions: The sole responsibility of the manufacturer under the Warranty period is limited to either repair or, at the option of the manufacturer, replacement of The Judge 2.0. There are no expressed or implied warranties, including those of fitness for a particular purpose of merchantability, which extend beyond the face hereof. Some states do not allow limitation on how long an implied warranty lasts, so the above Limitations may not apply to you.

Returns should be sent with an explanation of the problem including your physical address (no PO Boxes), proof of purchase, and telephone number. If the information is not included there will be a delay in the repair or replacement of your unit. If the unit is out of warranty, there is a \$62.00 Service fee.

Send to:

ROCKY MOUNTAIN RADAR

6469 Doniphan Drive

El Paso TX 79932

Phone: 915-587-0307 Fax: 915-587-6408

Accessories:

The following accessories and parts are available:

Windshields mount

Suction Cups (set of 3)

2 amp fuses (two each)

Power Cord

Replacement Owner's Manual

Carrying Case

(Free manual online download from our website)

A \$10.00 shipping and handling fee will be added to the total of each order.

PayPal, VISA, MasterCard, AMEX and Discover Accepted

IS IT LEGAL?

The Rocky Mountain Radar scramblers conform to all FCC rules and regulations. Part 15 of the FCC code regulates consumer products that may leak or transmit radio frequency energy into the atmosphere. Since the scramblers are not transmitters, these sections do not apply.

The radar scrambler is a *reflective receiver* and has no emissions. **It does not transmit**, but uses the police radar gun's own signal as a carrier of its information. The laser scrambler transmits a series of light pulses. There are no laws regarding the transmission of invisible light.

Rocky Mountain Radar does not condone the use of excessive speed on the highways, nor does it endorse breaking the speed limit laws of the United States of America. Please drive safely when using this or any other electronic product in your car.

FREQUENTLY ASKED QUESTIONS

Can I test it with roadside trailer radars?

The trailers you see on the side of the road that show your speed are not legal to write tickets. They do not contain the sophisticated sampling computers that are in police radar guns. Since our units confuse the computers and there is none, they will not work reliably against the trailers.

Can the police detect it?

The radar and laser scramblers do not have RF emissions and cannot be detected. **On The Judge 2.0 the new MMIC prevents detection of the radar detector completely.**

What states are they NOT legal in?

The Rocky Mountain Radar scramblers are **not** legal in Texas, Colorado, Utah, California, Nebraska, Oklahoma, Minnesota, Illinois, Tennessee, South Carolina (*unless the switchable scrambler feature is set to off*) and Virginia. The Rocky Mountain Radar detectors are **not** legal in commercial vehicles in most states. Use caution in these states.

What is Punch-Through?

The signal reflected by the car gets stronger the closer the target is to the radar gun. The Rocky Mountain Radar scrambler uses the radar signal as a carrier and reflects it through a high-gain antenna. It will work only as long as the scrambling signal is greater than the signal from the target. Punch-through is when these signals are equal or within 50-200 feet.

What is the effective range?

The radar scrambler works at four to six times the range of the radar gun. The laser scrambler is effective at more than two times the Lidar range.

How do I know the scrambler is working?

When you turn the unit on and it goes through the self-test (at start up the unit does a self-test as long as the Self-Test mode is on), to confirm all the circuits in the scrambler are working correctly. You will see “Scrambler On” if the scrambler is activated.

Why won't my unit turn on?

Check the following:

- 1) The on/off thumbwheel on the side of the unit
- 2) The fuse in the power cord. (To check the fuse in the power cord, unscrew the silver tip end that plugs into the cigarette lighter. If the fuse is blown, replace with a 2 amp fast burning fuse).
- 3) The fuse for your cigarette lighter.
- 4) If it is none of these, return the unit to the manufacturer for repair/replace at our discretion.

Where is the best place to mount my unit?

The manufacturer recommends in the upper center of the windshield (right below the rear-view mirror) for the maximum coverage. There can be no metallic interference with the unit.

What does the Voltage Meter do?

The Voltage Meter Checks and displays your vehicles battery voltage when the mode is activated.

What is the (EWD) K Filter?

The EWD is a K filter that The Judge 2.0 has to help prevent false alarms caused by some safety features in newer vehicles, for example Blind-spot/side-assist/anti-collision warning and other safety technology that operate in K Band.

I only see a small dot on my display, what happened?

The unit is in Dark Mode. In Dark Mode the unit only shows a small dot moving from left to right. Press the Dim Button (momentary contact) to adjust to your desired setting.

What is the purpose of having selectable Radar bands?

The unit features a new way for you to control what bands you want in your radar detector. The end user can choose what radar bands to activate or de-activate to their preference, giving you more options of operation,

What is the Traffic Safety Rejection Filter for?

The TSRF eliminates alerts from roadway traffic sensors that are used to monitor the flow of traffic on major roadways in various larger cities.

What is the difference between K/Ka Narrow/ Wide?

When on Wide mode the unit will pick up all signals around; some may be false signals from buildings or other vehicles. Since these signals are valid signals the detector will display them as detection. On Narrow mode the unit will shorten slightly the distance and reduce the false alarms.

For a complete list of FAQ's please visit our website
www.rockymountainradar.com

CONGRATULATIONS!

Congratulations on your purchase of a Rocky Mountain Radar product.

Please read the following information carefully.

TO QUALIFY FOR TICKET REBATE PROGRAM, YOU MUST HAVE PROOF OF PURCHASE AND BE A USER OF A THE JUDGE 2.0

NO TICKET WILL BE PROCESSED WITH OUT THE PROOF OF PURCHASE

The one year ticket rebate program covers tickets that are within the guidelines. It **does not** cover insurance costs or other incidental costs.

Rocky Mountain Radar administers the program. Rocky Mountain Radar shall not be liable for direct, indirect, incidental or consequential damages from participation in this program.

Rocky Mountain Radar **does not** endorse excessive speeds over the posted limit. Please drive carefully. To ensure prompt processing of claims, be sure to enclose all required documents. **All claims are verified through the court systems and may take up to eight weeks to process.**

If you have any questions about the program or your claim, please **write** to:

Rocky Mountain Radar
6469 Doniphan Drive
El Paso, Texas 79932
(915) 587-0307
www.rockymountainradar.com

CONDITIONS OF **TICKET REBATE PROGRAM**

To qualify for the ticket rebate program:

1. Must have proof of purchase.
2. Verified owner of a radar and laser scrambler product **does not** exceed 15 miles per hour OR 30% over the posted speed limit, whichever is less.
3. The ticket **must** be issued by “RADAR” or “LASER” and “SPEEDING”.
4. Rebate **only valid** in the USA.
5. Verified owner must be the driver when ticket is issued to qualify for this program **for one full year** from the date of purchase.
6. Only the person who is the verified owner of the scrambler product is eligible for the rebate.
7. Does **NOT APPLY** where **DWI or DUI** is involved or in **school or construction zones.**
8. This rebate is not available in California or Tennessee or outside the USA.

LIMITS

The one year laser ticket rebate program covers speeding tickets that do not exceed 15 MPH or 30% over the posted limit whichever is less. Please use the chart to determine whether you have a claim.

POSTED SPEED LIMIT	MAXIMUM SPEED FOR REBATE
20	26
25	32
30	39
35	45
40	52
45	58
50	65
55	70
60	75
65	80
70	85

HOW TO FILE A CLAIM

To file a claim send in the following information in to the address below.

1. Proof of purchase verifying owner of RMR scrambler. If it does not have the address and telephone number please include with proof of purchase.
2. Legible copy of ticket (both sides).
3. Legible copy of court receipt as proof of payment.
4. Court address.

To: Rocky Mountain Radar
6469 Doniphan Drive
El Paso, Texas 79932

**Rocky Mountain Radar
6469 Doniphan Drive
El Paso, Texas 79932
(915)587-0307 Phone
(915)587-6408 Fax
Follow us on Facebook**

www.rockymountainradar.com